



**STACK IN ACCORDANCE TO
MARKINGS ON CONTAINER**

**STACK ONLY WHEN
FULL BY VOLUME**

MAX 2 UNITS HIGH

LAB PACK USERS:

A copy of the Special Permit is available from the container supplier or the factory and is required for shipment.

Only the authorized marking on the container governs the proper use and restrictions of the container. The UN marking is located on the front of the container and has information such as the packaging type, group, stack test load, permissible net mass, etc.

(49 CFR 178.702-3 marking of IBCs-178.707 (c)5(ii))

The outer packaging must be secured to any detachable pallet to ensure stability in handling and transportation. Where a detachable pallet is used, its top surface must be free from sharp protrusions that might damage the IBC.

Consult factory for pallet details


IMPORTANT NOTICE

Always lift containers vertically using ALL FOUR LIFT STRAPS.



Lifting fallen containers should be done with an eye-and-eye sling, or an endless sling threaded through ALL four loops.

When righting a fallen container, be sure that the sling loops are lower than the bag loops. Lift by both eyes or one eye using a choker technique.



13H4 Flexible Composite Container with Lift Straps - For Solids ONLY -

MATERIALS INCLUDED:

Container, Liner, Cable Ties

MATERIALS NOT INCLUDED:

For 36 x 36 x 36 containers - use a 40" x 40" pallet (optional)

For 42 x 42 x 42 containers - use a 45" x 45" pallet (optional)

(2) 3/4" Roofing Nails (optional)

SET UP INSTRUCTIONS

1 Containers arrive knocked down. Place the pre-assembled container on a surface free from sharp protrusions that might damage the container. Pull one side up.



2 Unfold the sides of the container and square opening. Adjust the poly liner and gently tuck the liner into the bottom corners. Fold the excess liner over the outside of the container.



(Product color may vary from illustrations)

3 Set unit upright on a base pallet. (If attaching the container to a pallet, use 3/4" long roofing nails. Nail through the attached tabs into the pallet.)

Containers prepared for shipment must **NEVER** overhang pallet or container failure may occur.

4 After filling the container, gather top of liner and twist. Wrap the enclosed cable tie around twisted portion approx 6 inches down from the end. Tighten and secure the cable tie.

5 The cover is comprised of two integrated flaps. Fold either flap across the container and secure by tying several half hitch knots with the fabric ties attached to the corners of the container. Fold the second fabric cover across the first and secure in the same manner.

